### PRODUCT SPECIFICATIONS

For current product specifications, please to go www.griffin-stands.com and type the model number into the search bar. Locate the product listing to view the current factory specifications.

### TROUBLE SHOOTING

Performance Issue, Uneven or Unstable- Make sure all nuts and bolts are tight on the product. If they are, then loosen all nuts and bolts 1 full turn counterclockwise, then go back and tighten each bolt only ½ turn tight. Then do a final tighten turn for another ½ turn tight. Next, Make sure there are not any missing nuts or bolts. Third, ensure all parts on the product are not broken or defective. Finally, Re-read the assembly instructions or watch the product demonstration video to ensure you have correctly assembled or are using the product properly with factory specifications.

Missing Parts- The pictures, videos and images shown in this manual might have changed style or count due to the product being redesigned. So in rare cases the part may no longer be included or of a different style. However, if you think you are missing a part that is necessary to the assembly and use of your product, then first carefully double check all packaging for any parts you think are missing. Some parts might be hiding in the packaging or loose in an inner box.

## COMPANY INFORMATION AND SUPPORT

#### THANK YOU FOR YOUR PURCHASE

Thank you for purchasing the Griffin Snare Drum Stand. Your product comes with a 1 year factory warranty from purchase date. Please read all assembly instructions prior to assembling your new cart. Pictures that may aid in assembly can be found by going to www.griffin-stands.com and typing S80/S100/S2ST into the search bar.

Griffin™ stands and accessories are manufactured in several innovative factories responsible for developing products that address the newest needs and trends of the current market. We take pride in the Griffin™ brand and endeavor to be on the forefront of the musical stands and musical and lighting accessories market.






# User Manual Model# \$80/\$100/\$2\$T



Snare Drum
Stand

#### ASSEMBLY INSTRUCTIONS


**Step 1** – Take the main stand with legs and loosen the knob, spread the legs wide and tighten the knob to lock the legs in place as shown in Figure 1.



Step 2 – Insert the middle pipe trough the main stand. A memory lock is included in the part where you can adjust to lock the height adjustment in place. This will keep your preferred height. Turn the knob to tighten in place (See Figure 2). Then adjust the height of the stand by sliding up or down the top interlocking pipe to achieve your preferred height.



**Step 3** – Just below the snare drum basket is a knob which you can adjust according to your preferred angle. Insert your snare drum and use the circle knob just at the bottom of the basket to close the basket claws and secure the snare drum in place (See Figure 3).



Step 4 – If the top pipe is sliding, turning or dropping, then you need to secure the top pipe by using the supplied memory lock. First, Make sure the memory lock is tight by using a drum key to tighten it. Then lock the lip on the memory lock into the slot fitted for the memory lock on the bottom coupler pipe. This will interlock the top pipe with the bottom pipe which will fix the sliding and/or turning problem. Please refer to Figure 2 where the memory lock is. Please see YouTube video URL https://youtu.be/Z aM3p10aiU

**Step 5** – For safety reasons, please always make sure to test the stability and safety of the product before use. Double check all nuts and bolts, knobs and connectors, make sure that these are tight and securely fastened before use of your product. Test the product under light use or light loads the first time to confirm assembly and structure of the product is correct.

# ASSEMBLY AND DEMONSTRATION VIDEO

Please scan the QR Code below for the product demonstration video. Or go to the URL shown here and find the product video. www.Griffin-Stands.com/Videos



