

## User Manual SP28



Thank you for your purchase of your new SP28 PA Speaker Stands. These stands are fully assembled, but we're including some instructions to make their use a little easier and safer. A photo of the finished product can be found by going to [www.griffin-stands.com](http://www.griffin-stands.com). Type SP28 into the search bar. Please read all instructions before beginning assembly.



To set up your stands, loosen the knob at the tripod portion of your stand. Push down firmly and the tripod will extend. Keep extending the stand until the feet are approximately 18" (46cm) apart. If the tripod starts to narrow again, you have gone too far. (OVER EXTENSION OF THE TRIPOD CAN CAUSE FAILURE OF THE STAND UNDER LOAD.) Tighten the knob to hold the tripod in place.

Loosen the knob located near the top of the stand and pull the center post up to the desired height. Place the attached pin in the hole and tighten the knob. (FAILURE TO USE THE PIN WILL CAUSE STAND FAILURE UNDER LOAD.) Place your speaker on top and you're ready to rock.

