PRODUCT SPECIFICATIONS

For current product specifications, please to go www.griffin-stands.com and type the model number into the search bar. Locate the product listing to view the current factory specifications.

TROUBLE SHOOTING

Performance Issue, Uneven or Unstable- Make sure all nuts and bolts are tight on the product. If they are, then loosen all nuts and bolts 1 full turn counterclockwise, then go back and tighten each bolt only ½ turn tight. Then do a final tighten turn for another ½ turn tight. Next, Make sure there are not any missing nuts or bolts. Third, ensure all parts on the product are not broken or defective. Finally, Re-read the assembly instructions or watch the product demonstration video to ensure you have correctly assembled or are using the product properly with factory specifications.

Missing Parts- The pictures, videos and images shown in this manual might have changed style or count due to the product being redesigned. So in rare cases the part may no longer be included or of a different style. However, if you think you are missing a part that is necessary to the assembly and use of your product, then first carefully double check all packaging for any parts you think are missing. Some parts might be hiding in the packaging or loose in an inner box.

COMPANY INFORMATION AND SUPPORT

Thank you for your Purchase

Thank you for purchasing the Griffin Saddle Drum Throne. Your product comes with a 1 year factory warranty from purchase date. Please read all assembly instructions prior to assembling your new cart. Pictures that may aid in assembly can be found by going to www.griffin-stands.com and typing TR200 into the search bar.

Griffin™ stands and accessories are manufactured in several innovative factories responsible for developing products that address the newest needs and trends of the current market. We take pride in the Griffin™ brand and endeavor to be on the forefront of the musical stands and musical and lighting accessories market.





User Manual Model# TR200




Saddle Drum Throne


ASSEMBLY INSTRUCTIONS

Step 1 – Take the main stand with the legs, flip it, loosen the knob and spread the legs using two hands. Use the locking knob and turn to tighten in place. (See Figure 1 and 2). Flip the stand and make sure that the legs are flat on the floor.






Step 2 – Insert the center post through the bottom of the saddle seat and tighten the knob to keep in place. Also, you need to check the bolt (as seen on Figure 3) and make sure it is tightened well by using an allen wrench.



Step 3 – The knob near the center post is to tighten or loosen the spinning inner post with makes the seat swivel, you may or may not adjust this depending on your preference. If you do not want the seat to swivel just tighten the knob (refer to Figure 4). To raise and lower the seat just loosen the knob and turn the seat.

Step 4 – For safety reasons, please always make sure to test the stability and safety of the product before use. Double check all nuts and bolts, knobs and connectors, make sure that these are tight and securely fastened before use of your product. Test the product under light use or light loads the first time to confirm assembly and structure of the product is correct.



Step 5 – (If purchased with optional back rest) on the underside of the seat there are bolt holes to screw in the metal pipe and on the top part of the metal pipe will also be bolt holes to screw and attach the back rest. Make sure not to tighten each bolt all the way through to make sure that all bolts can be inserted. After installing all bolts to the seat, that is the time to tighten all bolts by 1 turn each to secure the level of the back rest.

ASSEMBLY AND DEMONSTRATION VIDEO

Please scan the QR Code below for the product demonstration video. Or go to the URL shown here and find the product video. www.Griffin-Stands.com/Videos



